



Válvulas de control direccional

Válvula eléctrica de control direccional



○ Código de símbolos

3C2		2B2B		2B2BL		
3C3		2B3B		2B3BL		2B 2
3C4		2B4B		2B4BL		2B 3
3C5		2B5B		2B5BL		2B 8
3C6		2B6B		2B6BL		
3C7		2B7B		2B7BL		2B 2L
3C9		2B9B		2B9BL		2B 3L
3C10		2B10B		2B10BL		2B 8L
3C11		2B11B		2B11BL		
3C12		2B12B		2B12BL		
3C25		2B25B		2B25BL		
3C29		2B29B		2B29BL		

○ Descripción de modelo

FW	-	X	X	-	X	-	X	X	/	X	X	50	*
Electrical operated directional control valve													Remarks
Specification													Serial number
02 6 NS6													50 Rexroth type
03 10 NS10													60 Vickers type
													70 Yuken type
Connect type													Seal material
0 m it Plug type													NBR
Z6													FPM
Z6 Wire box type													0 m it No damp
													08 ø0.8 Damp
													10 ø1.0 Damp
													12 ø1.2 Damp
Function code													0 m it without emergency push rod
Details as following symbol table													N9
Working voltage													N9 With emergency push rod
D 12 DC 12V													
D 24 DC 24V													
A 110 AC 110V													
A 220 AC 220V													
B 110 AC 110V Rectified													
B 220 AC 220V Rectified													
													Z4 Square connector
													Z5 Large square connector
													Z5L Square connector with light